

# CRAFTA FORMS

FINISHES STUDIO




# 108

## ACUFORMS -CFMH3DW3 3D Wushan Mountain Acoustic Panel

**ACUFORMS-CFMH3DW3-3D Wushan Mountain Acoustic Panel** are premium decorative acoustic panels designed to enhance interiors while reducing noise. Made from 100% polyester fiber, these 3D acoustic wall panels offer excellent sound absorption, modern aesthetics, and customizable colors, making them ideal for stylish interior wall applications.





# Acuforms-CFMH3DW3 3D Wushan Mountain Acoustic Panel

ACUFORMS CFMH3DW3 3D Wushan Mountain Acoustic Panels combine modern design with high-performance sound control. Made from 100% polyester fiber, these decorative acoustic panels are formed using high-temperature pressing to create durable, seamless shapes. Moreover, their 3D structure enhances sound absorption by utilizing internal cavity performance. As a result, they function effectively as sound absorbing wall tiles in both residential and commercial interiors. Additionally, these acoustic wall panels for interiors are eco-friendly, lightweight, and flame-retardant, making them a reliable solution for noise reduction and modern wall design.

## FINISHES



## MATERIAL

100 % Polyester


## DIMENSION

Size	410x410 mm
Thickness	45.0 mm
Water Absorption	Very Low
Fire Resistance	B1 (Fire Safe)
Length	Customized
Eco Grade	E1

## SURFACE FINISHES

Polyester Fiber

## DIMENSIONAL DETAIL



NOTE: Multiple colors available on request.

[Download .dwg](#) ↓



# Finishes

ACUFORMS CFMH3DW3 3D Wushan Mountain Acoustic Panels feature a smooth surface finish that enhances their clean and modern look. They are available in a wide range of customized colors to match different interior themes. The finish is durable, fade-resistant, and easy to maintain, making it suitable for both residential and commercial applications.




## CFMH3DW3

Available in Multiple Colors




# Installation Detail


ACUFORMS CFMH3DW3 3D Wushan Mountain Acoustic Panels can be installed using adhesive, nails, or a combination of both. Begin by cleaning the wall surface and marking reference lines for correct alignment. Apply construction glue evenly on the back or place nails through the panel into the substrate. Press firmly to ensure full contact. Panels can be trimmed or shaped using standard cutting tools for corners, joints, or custom layouts. Allow proper curing time for secure and long-lasting installation.




1. Prepare Wall and Panel



2. Apply Adhesive Gum



3. Press to Wall



4. Roll to Secure Panels



# Connect with Us

**Where ideas meet materials.**  
Let's create spaces that speak  
through surface, texture, and  
detail.

[ask@craftaforms.com](mailto:ask@craftaforms.com)

[craftaforms.com](http://craftaforms.com)

[@insta.craftaforms](https://www.instagram.com/insta.craftaforms)

CRAFTA  
FORMS  
FINISHES STUDIO